



32

40

230

37

44

1. ALL BUSSES TO HAVE A 6° DRAFT
2. ALL HOLES LABELED "TIC HOLE 6°" HAVE A COMPOUND ANGLE
3. SEE 100-2032-000 FOR OTHER CASTING DIMENSIONS

SECTION A-A

48

How do I create an eDrawing?

Mouse position: 8.16.21.99

Start [Icons] [Box Microsoft Exploring-D\Ne... AutoCAD 2000-...

231

32

40

232

37

SECTION F-H
SCALE 2:1

DETAIL B
SCALE 2:1

DETAIL C

SECTION D-D

49

233

wing Vie... [Icons] [untitled-Point] [Icons] 4:35PM

eDrawing Viewer -- Pump2.edw

File View Help

Virtual Folding

44

SECTION D-D

49

How do I create an eDrawing?

Mouse position: 8.7.18.79

Start [Icons] [Box Microsoft Exploring-D\Ne... AutoCAD 2000-...] [eDr

234